SCHEDA ATTREZZATURA PER MANUTENZIONE POMPE SERIE 47
MAINTENANCE TOOL CHART FOR PUMPS 47 SERIES

PARTICOLARE DA SOSTITUIRE *PART TO REPLACE*		ATTREZZO ESTRAZIONE *REMOVING TOOL*			ATTREZZO INSERIMENTO *INSERTION TOOL*		
CODICE *PART NO.*	**DESCRIZIONE** *DESCRIPTION*	**CODICE** *PART NO.*	**DESCRIZIONE** *DESCRIPTION*	**UTILIZZARE CON** *USE WITH*	**CODICE** *PART NO.*	**DESCRIZIONE** *DESCRIPTION*	**UTILIZZARE CON** *USE WITH*
90162500	OIL SEAL D. 22x32x5,5				26083500	OIL SEAL INSERTION TOOL	
90264200	PACKING D. 16x30x7/4	27179700	PACKING EXTRACTION SOCKET Ø16	USE WITH EXTRACTOR 26019400	26499300	PACKING INSERTION GUIDE	USE WITH DRIVE STUD 26134600
90270500	PACKING D. 20x35x7,5/4,5 H.P.	26093400	PACKING EXTRACTION SOCKET Ø20	USE WITH EXTRACTOR 26019400	26014000	PACKING INSERTION GUIDE	USE WITH DRIVE STUD 26134600
90272500	PACKING D. 22x35x7/4,5 H.P.	26093500	PACKING EXTRACTION SOCKET Ø22	USE WITH EXTRACTOR 26019400	26014000	PACKING INSERTION GUIDE	USE WITH DRIVE STUD 26134600
90274500	PACKING D. 24x35x6/4 H.P.	26093600	PACKING EXTRACTION SOCKET Ø24	USE WITH EXTRACTOR 26019400	26014000	PACKING INSERTION GUIDE	USE WITH DRIVE STUD 26134600
90164800	OIL SEAL D. 30x55x7				26083600	OIL SEAL INSERTION TOOL	