

| | | | | |
|-----------------------------------------------------------------------------------|----------------------------------------|-------------------------------------------|----|----------|
|  | EQUIPAGGIAMENTI TECNICI LAVAGGIO | EIETTORI DETERGENTE DETERGENT INJECTOR | ① | 7 |
| | | | GB | |



TABELLA PORTATE CONSIGLIATE
RECOMMENDED FLOW CHART

| UGELLO mm | NOZZLE inch. | PORTATA CONSIGLIATA l/min | RECOMMENDED FLOW USG p.m. |
|--------------|-----------------|------------------------------|------------------------------|
| ø1.2 | 0.047" | 3 ÷ 5 | 0.79 ÷ 1.32 |
| ø1.5 | 0.059" | 5 ÷ 8 | 1.32 ÷ 2.11 |
| ø1.8 | 0.071" | 8 ÷ 12 | 2.11 ÷ 3.17 |
| ø2.1 | 0.083" | 10 ÷ 15 | 2.64 ÷ 3.96 |
| ø2.3 | 0.090" | 12 ÷ 18 | 3.17 ÷ 4.76 |
| ø2.5 | 0.098" | 14 ÷ 22 | 3.70 ÷ 5.81 |
| ø2.7 | 0.106" | 17 ÷ 26 | 4.49 ÷ 6.87 |

N.B. GLI EIETTORI DETERGENTE FUNZIONANO SOLO SE LA CONDOTTA IN USCITA DALL' INIETTORE (OUT) E' IN BASSA PRESSIONE; UTILIZZARE TUBO ADEGUATO ALLA PORTATA EVITANDO STROZZATURE E GOMITI.

N.B. THE DETERGENT INJECTORS FUNCTION ONLY IF THE EXIT CHANNEL FROM THE INJECTOR (OUT) IS AT LOW PRESSURE; USE AN APPROPRIATE TUBE FOR THE FLOW THAT AVOIDS CHOKING AND BENDS.

